



SAL Protection Plan's peace of mind motoring doesn't end with repair coverage/services.

The benefits below apply to your on-road motorcycle and scooter no matter which Coverage/Services option you choose.

For over forty-five years, we've been there when our customers needed us most.

For true peace of mind, each SAL Protection Plan is backed by either SAL Marketing Inc., IAP Marketing or Industrial Alliance Pacific General Insurance Corporation, all members of the Industrial Alliance Group of companies.

IAG's strength is demonstrated in its financial ratings from both A.M. Best and Standard & Poor's.



This is a brochure, intended to outline the potential coverage/services offered and does not consist of a binding policy/contract. See your Policy/Contract for specific details.

Administration  
tel 1-888-444-9989  
fax 1-888-444-0697

Claims  
tel 1-888-444-0301  
fax 1-888-444-0675

2165 West Broadway Vancouver, BC, V6B 5H6



www.salgroup.com

Recreational Products Group

for New and Pre-owned Vehicles

The right plan for you...

Protection from unexpected repair bills down the road



Proudly Canadian



	Basic	Extra	Superior	
	B	E	S	
	•	•	•	1. Engine
	•	•	•	2. Turbocharger/Supercharger
	•	•	•	3. Transmission
	•	•	•	4. Transfer Case
	•	•	•	5. Primary Drive Components
	•	•	•	6. Secondary Drive Components
	•	•	•	7. Drive Axle
	•	•	•	8. Chain Case Components
	•	•	•	9. Oil Injection Components
	•	•	•	10. Cooling system
		•	•	11. Steering
		•	•	12. Brakes
		•	•	13. Electrical
		•	•	14. Fuel System
		•	•	15. Front and Rear Suspension
		•	•	16. Track Drive
			•	17. Seals and Gaskets
			•	18. Frame Package
			•	19. Trailer Package
			•	20. Touring Package
				21. Guaranteed Price Refund

...and your peace of mind




# Why purchase a SAL Protection Plan?

## It's coverage/ services when you need it most

The frequency of repairs increases with kilometres and time. SAL Protection Plan takes over when your manufacturer's warranty expires.

Warranty Term in km ('000's) & years



## The choice is yours

SAL Protection Plan puts you in the driver's seat. Choose the term that's best for you and your driving habits, then choose from two deductible levels: \$50 or \$100.



# Coverage of the following components means peace of mind for you and protection for your investment.

## B BASIC (clauses 1 to 10)

**1. Engine:** All internal lubricated parts contained within the engine including: Pistons, Piston Rings, Connecting Rods, Connecting Rod Bearings, Crankshaft, Crankshaft Main Bearings, Camshaft, Camshaft Bearings, Cam Followers, Timing Chain or Belt, Timing Chain Cover, Timing Gears, Timing Guides and Tensioners, Rocker Arms, Rocker Shafts, Rocker Bushings, Cylinder Head Valves, Valve Guides, Valve Lifters, Valve Springs, Valve Retainers, Valve Seats, Valve Seals, Valve Covers, Push Rods, Oil Pump and Housing, Oil Pan (excluding Drain Plug Threads), Intake and Exhaust Manifolds, Engine Mounts, Flywheel / Flexplate (excluding Teeth), Reed Valves and Block, Power Valve, Diaphragms, Rotary Valve and Shaft. **NOTE:** Cylinder Head(s), Engine Block / Crankcase and Cylinder Barrels are covered only if damaged by the failure of an internally lubricated part.

**2. Turbocharger / Supercharger:** (factory installed only) Turbocharger / Supercharger Housing (when damaged from within) and all internal lubricated parts including Turbine(s), Shaft, Bushings and Waste Gate.

**3. Transmission:** (automatic or standard) Transmission Housing (when damaged from within) and all internal lubricated parts, Transmission Oil Cooler (factory installed only), Oil Pan, Internal Selector Mechanism.

**4. Transfer Case:** Housing (when damaged from within) and all internal lubricated parts, Encoder Motor, Four Wheel Drive Control System, Switch, Sensors, Servos or Actuators, Module, Front Hub Coils.

**5. Primary Drive Components:** Housing (when damaged from within) and all internal lubricated parts including Sheaves, Gears, Bearings, Bushings.

**6. Secondary Drive Components:** Stationary and Moveable Sheaves, Secondary Shaft and Bearings, Bushings, Cam Assembly.

**7. Drive Axle:** Differential, Transaxle and Final Drive Housings (when damaged from within) and all internal lubricated parts, Locking Hubs, Drive shafts and yokes, Universal Joints, Constant Velocity Joints, CV Boots, Axle Shafts, Four Wheel Drive Actuator, Differential Covers, Supports and Retainers, Locking Rings.

**8. Chain Case Components:** Housing (when damaged from within) and all internally lubricated parts including Shafts, Gears, Sprockets, Chain and Adjuster Mechanism, Reverse Gear Components, and Housing (when damaged from within).

**9. Oil Injection Components:** Oil Injection Drive Gear, Oil Tank, Oil Level Sensor, Oil Lines, Oil Injection Metering System, Oil Pump.

**10. Cooling System:** Engine Cooling Fan Motor, Water Pump, Radiator, Thermostat, Temperature Gauge, Sending Unit, Cooling Fan Sensor / Switch.

## E EXTRA (Basic + clauses 11 to 16)

**11. Steering:** Steering Stem including Bearings, Bushings and Nut. Steering Stem Shaft, Axle, Handle Bar and Tie-Rod Ends. Steering Links / Steering Link Ends, Spindle Bushings, Steering Box, Idler Arm, Pitman Arm, Rack and Pinion Assembly.

**12. Brakes:** Master Cylinder, Calipers, Hydraulic Brake Lines and Fittings, Drum Brake Actuating Cam and Backing Plate.

**13. Electrical:** Alternator / Generator, Magneto, Rotor, Stator, Rectifier, Voltage Regulator, Starter Motor, Starter Solenoid, Starter Drive, Wiring Harness, Distributor, Ignition Coil, Engine Control Module, Electronic Ignition Module / CDI, Electronic Fuel Injection Control Module / Sensor, Ignition Switch, Ignition Switch Lock Cylinder, Stop Lamp Switch, Head Lamp Switch, Turn Signal Switch, Manually Operated Electrical Switches and Gauges.

**14. Fuel System:** Fuel Pump, Fuel Injection Pump, Fuel Injector(s), Fuel Tank, Fuel Tank Sending Unit, Metal Fuel Lines and Fittings, Fuel Pressure Regulator, Petcock.

**15. Front and Rear Suspension:** All internally lubricated parts of Front Fork Tubes and Front Hub, Swing Arm (including Bearings and Bushings), Swing Arm Shaft, Control Arms, Ball Joints, Wheel Bearings, King Pins and Bushings, Spindle.

**16. Track Drive:** Tracks (non-studded only), Drive Shaft / Axle, Drive Sprockets, Bearings, Bushings, Collars, and Flange Plates, Track Guide Wheels and Slide Rails.

## S SUPERIOR (Extra + clauses 17 to 20)

**In addition to all the listed components, we will pay for any breakdown of all other parts except those listed under Exclusions in your Policy/Contract.**

The following Coverage/Services are optional under Basic and Extra Coverage/Services. (An additional charge will apply.)

**17. Seals and Gaskets:** All Seals and Gaskets are covered for components listed above in the selected Schedule of Coverages. **NOTE:** Seepage excluded.

**18. Frame Package:** Axle(s), Brackets, Hubs, Spring Hangers, Welds, Couplers, Suspension Springs and Fenders.

**19. Trailer Package:** (coverage applies to a trailer if purchased at the same time as your vehicle) Master Cylinder, Hydraulic Brake Actuator, Backing Plates, Trailer Frame Welds, Spring Hanger Brackets and U-Bolts, Axles, Spindles and Wheel Bearings, Manual Winch.

**20. Touring Package:** Dash Components, Factory Installed Sound System (excluding Speakers ) and Control Cables.

**The following Coverage/Services are optional under ALL PLANS – An additional charge will apply.**

**21. Guaranteed Price Refund:** Referred as "GPR" in your Policy/Contract.

